SILVERCREST®

7

Under-Cabinet Radio SKRD 30 A1




(GB) (CY) **Under-Cabinet Radio**
Operating instructions


(HR) **Ugradbeni radio**
Upute za upotrebu

KOMPERNASS GMBH
BURGSTRASSE 21 · D-44867 BOCHUM
www.kompernass.com
ID-Nr.: SKRD 30 A1-09/10-V3

A


16
15
1
2
3
SILVERCREST
Snooze /Timer
Lock
Band/AMS
On/Off
AOT
Main
Mode
Preset-
Preset+
Tune-
Tune+
4
5
6
7
8
9
10
11
12
13
14
17
18
19
20
20

B


4 cm

GB
CY

Index

Introduction 2
Information for these operating instructions 2
Copyright 2
Proper usage 2
Warning notices 3
Safety 4
Danger from electric shock. 4
Handling of batteries 4
Basic Safety Instructions 5

Operating components 6

Setting up and connecting . . . 7
Safety instructions 7
Package contents and transport inspection 7
Unpacking 7
Disposal of the packaging 8
Set-up location requirements. 8
Electrical connection. 8
Inserting the battery 9
Mounting under a wall cupboard . . 9
Disassembly 10
Setting up the device 10
Providing mains power 10
VHF wire antenna 10

Handling and operation . . . 11
Switching On and Off 11
Basic settings 11
Activating the settings menu 11
Setting the time 12
Setting the date 12
Adjusting the display brightness . . . 13
Setting the memory function 13
Setting the time of day format 14
Kitchen timer. 14
Setting the kitchen timer 14
Starting the kitchen timer 15
Pausing the kitchen timer. 15
Programming the kitchen timer 16
Accessing the kitchen timer 16
Programming alarm wake times . . . 17
Wake with alarm tone 17
Waken with radio. 18
Switching the alarm off. 18
When the wake time has arrived . . 18
Radio operation 19
Switching the radio on/off 19
Adjusting the volume. 19
Manual station selection. 19
Search for the next station 19
Saving stations manually 20
Access saved stations 20
Automatic station search (AMS function) 20
Additional functions 21
Automatic switch off (Sleep function) 21
Button lock 21
Bass accentuation. 21

Cleaning 22
Safety instructions 22
Cleaning the housing 22

Troubleshooting 22
Safety instructions 22
Malfunction causes and remedies . 23

Storage/Disposal 24
Storage. 24
Disposal of the device 24
Disposing of the batteries 24

Appendix 25
Information regarding the EG conformity declaration 25
Technical data 25
Warranty 26
Service 26
Importer 26

GB
CY

Introduction

Information for these operating instructions

These operating instructions are a component of the Under-Cabinet Radio SKRD 30 A1 (henceforth designated as the device) and they provide you with important information about the intended use, safety, installation and connection as well as operation of the device.

The operating instructions must be kept available in the vicinity of the device at all times. They are to be read and used by anyone assigned to service and repair faults in the device.

Retain these operating instructions and pass them on with the device to any future owners.

Copyright

This documentation is copyright protected.

Any copying or reproduction, including as extracts, as well as the reproduction of images, also in an altered state, is not permitted without the express written consent of the manufacturer.

Proper usage

This device is only intended for the reception of VHF radio programmes, as a kitchen timer and as an alarm by means of an alarm tone or radio in enclosed spaces. The device is intended as a free standing unit or for mounting under a cupboard. For these purposes the supplied stand and/or mounting plate must be used. Any other use or uses beyond those mentioned are considered unintended use. The device is not intended for use in commercial or industrial environments.

⚠ WARNING

Danger from unintended use!

Danger from the device can result if it is used for unintended purposes and/or other types of use.

- ► Use the device exclusively for intended purposes.
- ► Observe the procedures described in these operating instructions.

No warranty claims of any kind will be accepted for damage caused by improper use, unauthorised repairs, unauthorised modifications or for the use of unapproved replacement parts.

The operator alone bears liability.

Warning notices

In the current operating instructions the following warning notices are used:

⚠ DANGER

A warning in this danger level indicates a hazard threatening situation.

In the event that the hazardous situation is not avoided it can lead to death or serious injury.

► The directives in this warning are there in order to avoid the danger of death or serious injury.

⚠ WARNING

A warning of this danger level signifies a possible dangerous situation.

If the dangerous situation is not avoided it can lead to injuries.

► The directives in this warning are there to avoid personal injuries.

IMPORTANT

A warning of this danger level signifies possible property damage.

If the situation is not avoided it can lead to property damage.

► The directives in this warning are there to avoid property damage.

NOTICE

► A notice signifies additional information that assists in the handling of the device.

GB
CY

Safety

In this section you receive important safety information regarding handling of the device.

This device complies with the statutory safety regulations. Incorrect usage can lead to injuries and property damage.

Danger from electric shock

⚠ DANGER

Risk of fatal electrocution!

A life-threatening situation can arise from contact with live wires or components!

Observe the following safety instructions to avoid electric shock hazards:

- Do not use the device if the mains power plug or the connection cable are damaged.
- Do not, under any circumstances, open the device housing. The risk of an electric shock is present if the power carrying connections are touched or the electrical or mechanical construction is changed.

Handling of batteries

⚠ WARNING

Danger from improper use!

For safe handling of batteries observe the following safety instructions:

- Do not throw batteries into a fire.
- Do not short circuit batteries.
- Do not attempt to recharge batteries.
- Regularly check the condition of the batteries. Leaking battery acid can cause permanent damage to the device. Special caution should be shown when handling damaged or leaking batteries. Danger from acid burns! Wear protective gloves.
- Store batteries in a place inaccessible to children. If swallowed seek immediate medical attention.
- If you do not intend to use the device for an extended period of time, remove the batteries.

Basic Safety Instructions

For safe handling of the device observe the following safety instructions:

- Before use check the device for visible external damage. Do not put into operation a device that is damaged or has been dropped.
- Damaged cables or connections should be replaced by authorised qualified persons or by the customer service department.
- Persons who, due to their physical, intellectual or motor abilities, are incapable of operating the device safely may only use the device under supervision or direction from a responsible person.
- Only allow children to use the device under supervision.
- Repairs should only be carried out by authorized specialist companies or by the customer service department. Incorrect repairs can result in danger to the user. In addition warranty claims become void.
- A repair to the device during the warranty period may only be carried out by a customer service department authorized by the manufacturer otherwise no additional warranty claims can be considered for subsequent damages.
- Defective components may only be replaced with original replacement parts. Only by using original replacement parts can you guarantee that the safety requirements are complied with.
- Protect the device from moisture and liquid penetration. Never submerge the device in water, do not place the device in the vicinity of water and do not stand any object filled with liquid (i.e. vases) on the device.
- Do not place any objects on the device.
- Do not operate the device in the vicinity of open flames (i.e. candles).
- Avoid direct sunlight.
- Always pull on the power plug when disconnecting from the wall socket, never pull on the connection cable.
- If malfunctions occur or thunder storms threaten pull the power plug from the wall socket.

GB
CY

Operating components

(for illustrations see fold out sides figure A)

1. Mounting plate/Stand
2. Control panel
3. Display
4. On/Off: On/Off switch (Radio)
5. AOT: Timer switch off
6. Lock/Mem.: Button lock/memory slot selection
7. Bass/AMS/Mode: Bass accentuation/Station search/Access setting menu
8. Alarm 1: Alarm 1 programming
9. Alarm 2: Alarm 2 programming
10. Preset–: selection of the previous memory slot
11. Preset+: selection of the next memory slot
12. Tune–: Decrease the reception frequency
13. Tune+: Increase the reception frequency
14. VOLUME/Snooze/Timer: Volume control/Alarm switch off/Timer setting
15. Wire antenna for VHF reception
16. Mains connection cable
17. Recesses for stand
18. Speakers
19. Battery compartment
20. Unlocking buttons for the mounting plate

GB
CY

Setting up and connecting

Safety instructions

⚠ WARNING

Damage may occur to property and injuries to people when operating the device!

Observe the following safety instructions to avoid dangers:

- ► Packaging material should not be used as a play thing. There is a risk of suffocation!
- ► To avoid risks to persons and property, observe the requirements for the set-up location and the electrical connections.

Package contents and transport inspection

The device is delivered with the following components as standard:

- Under-Cabinet Radio SKRD 30 A1
- Mounting plate/Stand
- 4 Securing screws
- 1 x Battery 3 V Type CR2032
- Operating instructions

NOTICE

- ► Check the contents to make sure everything is there and for visible damage.
- ► If the items supplied are incomplete, or damaged due to defective packaging or transportation, contact the Service Hotline (see section ***Service***).

Unpacking

- ♦ Remove all device parts and the operating instructions from the carton.
- ♦ Remove all packing material.

GB
CY

Disposal of the packaging

The packaging protects the device from transport damage. The packaging materials are selected from the point of view of their environmental friendliness and disposal technology and are therefore recyclable.



The recirculation of packaging into the material circuit saves on raw material and reduces generated waste. Dispose of packaging material that is no longer needed according to the regionally established regulations.

NOTICE

► If possible preserve the device's original packaging during the warranty period so that in the case of a warranty claim you can package the device properly for return.

Set-up location requirements

For the safe and fault free operation of the device, the set-up location must fulfill the following conditions:

- When setting up the device place it on a firm, flat and even surface. Use the supplied stand.
- Set up or mount the device in such a way that the available ventilation openings and the speaker are not covered.
- Do not operate the device in a hot, wet or very humid location or in the vicinity of flammable materials.
- The surfaces of furniture may contain components that could affect and soften the rubber feet on the device. If necessary, place an anti-slip mat under the rubber feet of the device.
- The wall socket must be easily accessible so that, in an emergency, the plug can be quickly withdrawn from the socket.

Electrical connection

- Before connecting the device, compare the connection data (voltage and frequency) on the rating plate of the device with that of your power supply network. This data must be compatible to avoid possible damage to the device.
- Make sure that the device's connection cable is not damaged and is not laying over hot surfaces and/or sharp edges.
- Make sure that the connection cable is not tightly stretched or bent.
- Do not allow the connection cord to hang over edges (Trip wire effect).

Inserting the battery

By inserting the battery you can avoid the loss of programmed time of day and alarm times in the event of a possible power outage. The battery ensures that the internal clock continues to run even during a power failure. When power is restored the correct time appears automatically in the display 3.

NOTICE

► The device can also be operated without a battery.

- Open the cover of the battery compartment 19 on the underside of the device by turning the cover to the left, with a coin, as far as it will go and then lift off.
- Insert the battery type CR2032 (supplied) into the battery compartment. The side with the marking + points upwards.
- Close the battery compartment by attaching the cover and then with a coin turn it to the right.

Mounting under a wall cupboard

(Illustration see fold out side figure B)

With the supplied mounting plate 1 you can mount the device under, for example, a wall cupboard. For mounting of the device proceed as follows:

- Press both unlocking buttons 20 on the rear panel of the device downwards thereby, at the same time, sliding the mounting plate 1 backwards and remove the mounting plate 1.
- Find a suitable set-up location for the device (see also the section ***Requirements for the set-up location***).
- Hold the mounting plate 1 under the set-up location. Thereby the front edge of the mounting plate 1 should be approx. 4 cm behind the front of the cupboard so that, after Remove the mounting, the device is flush with the cupboard.
- Mark the 4 fastening points with a pencil.
- Using a spike or nail, make a small depression at the respective marking points. Screw the mounting plate 1 tightly with the supplied screws as illustrated in figure B.
- Place the device aslant, with the front recesses in the top face, in the mounting plate 1. Press the rear part of the device upwards against the mounting plate 1 until the device audibly locks into place.
- Check to make sure that the device is secure.

GB
CY

Disassembly

- Press both unlocking buttons 20 on the rear panel of the device downwards, thereby sliding, at the same time, the device forward and then remove the device downwards.
- Unscrew the screws on the mounting plate 1 and remove the mounting plate 1.

Setting up the device

As an alternative you can stand the device on a top. So as not to cover up the ventilation slots and the speaker 18 on the underside of the device, when setting up the device it must be mounted on the stand 1. For assembly of the stand proceed as follows:

- Press both unlocking buttons 20 on the rear panel of the device downwards thereby, at the same time, sliding the mounting plate 1 backwards and remove the mounting plate 1. The mounting plate can now be used as a stand.
- Slide both front retaining tabs of the stand 1 into the rear recesses 17 on the underside of the device.
- Press both rear retaining tabs of the stand 1 into the front recesses 17 on the underside of the device until the stand audibly locks into place.
- Find a suitable set-up location for the device (see also the section ***Requirements for the set-up location***).

Providing mains power

- Insert the mains connection cable 16 power plug into a socket. The time of day will be shown in the display 3 (0:00 o'clock).

VHF wire antenna

- Unwind the wire antenna 15 completely for VHF reception.

GB
CY

Handling and operation

In this section you receive important information for the handling and operation of the device.

Switching On and Off

After the device has been connected to the power supply it is already switched on. Via the On/Off ❹ button you switch between the operational modes clock/standby operation and radio.

NOTICE

► The On/Off switch ❹ does not disconnect the device completely from the mains power. To completely disconnect the device from the mains power the mains power cable plug ⓰ must be pulled from the mains socket.

Basic settings

After the device has been connected to the mains power supply it shows the time of day and the day of the week in the display ❸. The device is in the operational mode clock/standby operation.

Activating the settings menu

To activate the settings menu, whilst in the operational mode clock/standby operation, press the Bass/AMS/Mode ❼ button. The time of day, shown in the display ❸, begins to blink. Each further actuation of the Bass/AMS/Mode ❼ button switches to the next setting potential. The menu item sequence is:

- Setting the time of day
- Setting the date
- Adjusting the display brightness
- Setting the memory function
- Setting the time of day format

NOTICE

► The setting menu ends automatically if you do not actuate any buttons for approx. 15 seconds. The executed setting is saved.

GB
CY

Setting the time

Prerequisite: The device is in the operational mode clock/standby operation.

- Press the Bass/AMS/Mode 7 button once. The time of day indicator begins to blink.
- Set with the buttons Tune+ 13 and Tune– 12 the current time of day. With each button press the time of day changes by one minute. Holding down the respective button for more than 2 seconds starts the speed setting.
- Press the Bass/AMS/Mode 7 button again to save the current setting and move to the next menu item.

NOTICE

► The time of day will revert back to 00:00 o'clock if the device is disconnected from the mains power supply and no battery is inserted or if the battery is too weak.

Setting the date

Prerequisite: The device is in the operational mode clock/standby operation.

- Press the Bass/AMS/Mode 7 button twice. The date indicator begins to blink.
- Set with the buttons Tune+ 13 and Tune– 12 the current date. With each button press the date is changed by one day. The weekday indicator changes automatically. Holding down the respective button for more than 2 seconds starts the speed setting.
- Press the Bass/AMS/Mode 7 button again to save the current setting and move to the next menu item.

NOTICE

► The date will revert back to 01.01.2010: if the device is disconnected from the mains power supply and no battery is inserted or if the battery is too weak.

Adjusting the display brightness

Prerequisite: The device is in the operational mode clock/standby operation.

- Press the Bass/AMS/Mode ❼ button three times. The current setting for the display brightness is shown (H=bright or L=dim).
- Set, with the button Tune+ ⓭, the display brightness to H if you want the display to be brighter.
- Set, with the button Tune– ⓬, the display brightness to L if you want the display to be darker.
- Press the Bass/AMS/Mode ❼ button again to save the current setting and move to the next menu item.

Setting the memory function

You can set up to 10 date reminders to which an automatic reminder will be triggered. The function SdA (SdA=Special Day Alert) is useful as a reminder, for example, of birthdays or other recurring events. The reminder occurs every year on the same date.

Prerequisite: The device is in the operational mode clock/standby operation.

- Press the Bass/AMS/Mode ❼ button four times. The current setting of the selected reminder date is shown alternating with the indicator SdA. Next to the indicator SdA is the number of the memory slot for that date. Possible reminders are SdA 0 to SdA 0.
- Select with the buttons Preset+ ⓫ and Preset– ❿ the memory slot for the date to be set.
- Set with the buttons Tune+ ⓭ and Tune– ⓬ the date for this memory slot. With each button press the date is changed by one day. Holding down the respective button for more than 2 seconds starts the speed setting.

NOTICE

► Press the button AOT ❺ if you want to switch off the reminder function for the currently selected memory slot. In the display -- -- is shown.

- Press the button Lock/Mem. ❻ to set the time of day at which the reminder function is to be triggered. The setting is carried out with the buttons Tune+ ⓭ and Tune– ⓬ on the hour between 00 and 23. This setting applies to all programmed reminder dates
- Press the Bass/AMS/Mode ❼ button again to save the current setting and move to the next menu item.

GB
CY

Setting the time of day format

Prerequisite: The device is in the operational mode clock/standby operation.

- Press the Bass/AMS/Mode 7 button five times. The current setting for the time of day format is shown (24=24 hour format or 12=12 hour format).
- With the button Tune+ 13 set the time of day format to 24 if you want a time of day display in the 24 hour format .
- With the button Tune– 12 set the time of day format to 12 if you want a time of day display in the 12 hour format .
- Press the Bass/AMS/Mode 7 button again to save the current setting and move to the next menu item.

Kitchen timer

The device has a convenient kitchen timer with which, for example, cooking and baking times can be monitored. The programmable time range of the kitchen timer lies between 1 minute and 23 hours, 59 minutes.

Setting the kitchen timer

- Press the Snooze/Timer 14 button. The display shows 00:00. In the right upper corner of the display the saucepan symbol for the kitchen timer is superimposed.
- Turn the VOLUME 14 knob to set the time range for the kitchen timer. Turning in a clockwise direction increases the time; turning in a counter clockwise direction reduces the time.

NOTICE

► If, during the setting, approx. 15 seconds passes without any changes taking place the device reverts back to the previous operational mode.

Starting the kitchen timer

♦ After setting the time press the button Snooze/Timer 14 again. The displayed time begins to run backwards. In the right, upper corner of the display a backwards running clock is superimposed.

NOTICE

► If, during the operation of the kitchen timer, another function is selected the display of the remaining time fades out. The saucepan symbol and the backward running clock in the right, upper corner of the display, however, continue to be shown. Press the button Snooze/Timer 14 again to allow the remaining time of the kitchen timer to be shown once more.

30 seconds before the kitchen timer run time has expired the device begins to acoustically indicate, with individual signal tones, the arrival of the set time. Thereby the interval between the individual tones becomes shorter and shorter. When the set time has arrived the kitchen timer's alarm signal sounds as a continuous tone.

♦ Press the button Snooze/Timer 14 to switch off the kitchen timer alarm signal.

Pausing the kitchen timer.

♦ Press, while the kitchen timer is running, the button Snooze/Timer 14. The kitchen timer is paused. The displayed remaining time begins to blink.

NOTICE

► After approx. 15 seconds the device reverts back to the previous operational mode. Press the button Snooze/Timer 14 again to allow the remaining time of the kitchen timer to be shown once more.

♦ To restart the kitchen timer press the button Snooze/Timer 14 again. The kitchen timer restarts.

♦ To switch off the kitchen timer before the set time has expired press and hold down the Snooze/Timer 14 button for at least 2 seconds.

GB
CY

Programming the kitchen timer

You can preprogramme the kitchen timer with the most frequently used times so that it is not necessary to continually reenter them. Up to 10 times can be preprogrammed. All 10 memory slots are preprogrammed with 10 minutes as standard.

For the programming of the kitchen timer proceed as follows:

- Press the button Snooze/Timer 14 to activate the kitchen timer.
- Turn the VOLUME 14 knob to set the time to be programmed. Turning in a clockwise direction increases the time; turning in a counter clockwise direction reduces the time.
- Press the button Lock/Mem. 6 to activate the timer selection. Under the kitchen timer saucepan symbol a blinking T is shown.
- Select with the buttons Preset+ 11 and Preset– 10 a memory slot between T0 and T9 for the timer that is to be set.
- Press the button Lock/Mem. 6 again to programme the set time on the selected memory slot. The blinking T under the saucepan symbol is now showing constantly.
- Repeat the process for the other memory slots.

Accessing the kitchen timer

To access a programmed time for the kitchen timer proceed as follows:

- Press the button Snooze/Timer 14 to activate the kitchen timer.
- Select with the buttons Preset+ 11 and Preset– 10 the desired timer between T0 and T9.
- Press the button Snooze/Timer 14 again to start the kitchen timer.

GB
CY

Programming alarm wake times

The device has two alarms available. All settings for both alarms can be carried out independently from each other. You can select whether at the programmed time an alarm tone shall sound or the radio shall play.

NOTICE

► If, during alarm wake programming, no button is pressed for approx. 15 seconds the alarm will activate with the current settings.

Prerequisite: The device is in the operational mode clock/standby operation.

To set the wake time proceed as follows:

- Press the Alarm1 button 8 or the Alarm2 button 9. The set wake time of the respective alarm is shown blinking in the display 3 and the indicator A1 and/or A2 appears. The weekday on which this alarm is to be activated is shown above the time indicator.
- Set with the buttons Tune+ 13 and Tune– 12 the desired wake time. With each button press the wake time changes by one minute. Holding down the respective button for more than 2 seconds starts the speed setting.
- Press the button AOT 5 to switch between the weekday combinations Mo-Fr, Sa-Su or Mo-Su. The respective selected combination is shown above the wake time.
- Press and hold down the button AOT 5 for at least 2 seconds to switch between the weekday combinations and individual weekday setting alternatives.

NOTICE

► With the individual weekday setting alternative you switch between the days of the week with the button AOT 5.

Wake with alarm tone

Prerequisite: The device is in the operational mode clock/standby operation.

- To select "Alarm tone" for the respective alarm press the Alarm1 button 8 or the Alarm2 button 9 several times in succession until, in the display 3, the symbol appears.

GB
CY

Waken with radio

If you want to be woken by the radio, before activating the wake time carry out the following settings:

- Switch the radio on by pressing the On/Off ❹ button.
- Select the station with which you want to be woken (see section ***Station setting***).
- With the VOLUME ⓮ knob set the desired volume (see section ***Volume settings***).
- Switch the radio off by pressing the On/Off ❹ button.
- To select "Radio" for the respective alarm press the Alarm1 button ❽ or the Alarm2 button ❾ several times in succession until, in the display ❸, the symbol appears.

Switching the alarm off

Prerequisite: The device is in the operational mode clock/standby operation.

- To switch off the respective alarm press the Alarm1 button ❽ or the Alarm2 button ❾ several times in succession until no symbols are shown in the display ❸.

When the wake time has arrived

With the setting **"Wake with alarm tone"** a fourfold signal tone sounds in intervals of 2 seconds. The volume of the signal tone will continually increase until the maximum volume has been reached. The duration of the wake signal is restricted to 10 minutes.

With the setting **"Wake with radio"** the radio will switch on. The previously selected station will be activated for a maximum of 60 minutes at the set volume.

- Press the button Snooze/Timer ⓮ to activate a repeat wake after 9 minutes.

NOTICE

► The repeat wake function is possible up to 60 minutes after the set wake time has arrived.

- Press the Alarm1 button ❽ or the Alarm2 button ❾ to end the current alarm.

NOTICE

► The alarm becomes active again when the next wake time has arrived (i.e. on the next day).

Radio operation

NOTICE

- For a good radio reception the wire antenna 15 must be completely uncoiled. Adjust the antenna, whilst in radio operation, to the best reception.
- The technical factors of the device allow for tuning reception frequencies outside of the permitted VHF (FM) range of 87.5–108 MHz. In some countries, different national regulations may apply to the assigned radio frequency ranges.
 Please note that information received outside of the assigned radio frequency ranges may not be exploited, passed on to third parties or otherwise misused.

Switching the radio on/off

- Switch the radio on by pressing the On/Off 4 button.The display 3 shows the current reception frequency of the tuned station.
- Switch the radio off by pressing the On/Off 4 button again.The device changes back to the operational mode clock/standby operation. The current time of day is shown.

Adjusting the volume.

- With the VOLUME 14 knob set the desired volume. Turning in a clockwise direction increases the volume; turning in a counter clockwise direction reduces the volume. The volume level is shown on the left border of the display 3.

Manual station selection

- By a single press on the buttons Tune+ 13 and Tune– 12 tune the desired station. The frequency of the station is shown in the display 3. During the tuning the speaker is switched off.

Search for the next station

The device can automatically search for the nearest station.

- Press and hold down the button Tune+ 13 or Tune- 12 for at least two seconds. The device searches for the nearest station with sufficient reception quality.
- Repeat this process until you have found the station you are looking for.

GB
CY

Saving stations manually

Prerequisite: The device is in the radio operational mode.

The device has 30 memory slots available for station frequencies. To save a station frequency proceed as follows:

- Tune, as described previously, the desired station.
- Press the button Lock/Mem. ❻ once. The symbol MEM begins to blink in the lower, right corner of the display.
- Select with the buttons Preset+ ⓫ and Preset– ❿ the desired memory slot for the tuned station between *1* and *30*.
- Press the button Lock/Mem. ❻ again. The reception frequency of the tuned station is saved on the selected memory slot. The symbol MEM lights up constantly.

Access saved stations

Prerequisite: The device is in the radio operational mode.

- Select with the buttons Preset+ ⓫ and Preset– ❿ the desired memory slot for the saved station between *1* and *30*.

Automatic station search (AMS function)

Prerequisite: The device is in the radio operational mode.

To allocate the memory slots to the station frequencies with the strongest receivable stations a station search can be carried out.

NOTICE

- ► With the carrying out of the following described function all previously saved stations will be lost.

- Press and hold down the button Bass/AMS/Mode ❼ for at least two seconds. The device begins the station search and allocates to the memory slots 1-30 the found stations.

NOTICE

- ► If more than 30 stations are found only the first 30 reception frequencies will be saved.
- ► If less than 30 stations are found the last memory slots remain unchanged.

Additional functions

Automatic switch off (Sleep function)

With the sleep function the radio switches itself off after a time lapse of between 5 and 120 minutes.

- To access the function press the button AOT 5. The current remaining time until the radio switches itself off is shown.
- Press the button AOT 5 repeatedly to set the desired time. Holding down the button for more than 2 seconds starts the speed setting.

NOTICE

► The setable time frame lasts from 120 to 5 minutes. The setting takes place in stages of 5 minutes. After which the indicator OFF appears. With the indicator OFF the sleep function is switched off.

Button lock

You can lock the buttons of the device so that settings cannot be altered by unauthorised people or children.

- Press and hold down the button Lock/Mem. 6 for at least two seconds to switch the button lock on or off. When the button lock is switched on the symbol appears in the display.

Bass accentuation

With the bass accentuation you can switch on an enhanced playback of the low frequencies.

Prerequisite: The device is in the radio operational mode.

- Press briefly the button Bass/AMS/Mode 7 to switch the bass accentuation on or off. With the bass accentuation switched on the symbol BASS appears in the display.

GB
CY

Cleaning

Safety instructions

⚠ DANGER

Life-threatening situation from electric shock!

► Remove the plug from the mains power socket before cleaning.

IMPORTANT

Damaging of the device!

► Make sure when you are cleaning the device that no moisture gets inside in order to avoid irreparable damage to it.

Cleaning the housing

■ Clean the surfaces of the device with a soft, dry cloth.

Troubleshooting

In this section you receive important information for the localization and remedying of malfunctions. Observe the instructions in order to avoid danger and damage.

Safety instructions

⚠ WARNING

Observe the following safety information to avoid danger and property damage:

► Repairs to electronic devices may only be carried out by specialists who have been trained by the manufacturer. Considerable danger to the consumer and damage to the device can occur as a result of incorrect repairs.

Malfunction causes and remedies

The following table will help with localizing and remedying minor malfunctions:

Defect	Possible cause	Solution
The display is showing nothing.	The plug is not inserted.	Insert the plug into the mains power socket.
	Mains power socket is not supplying power.	Check the circuit fuse.
No sound	The volume is set to minimum.	Increase the volume with the VOLUME 14 knob.
	The radio is switched off.	Switch the radio on with the On/Off 4 button.
Noisy radio reception	The radio station is not properly tuned in.	Tune the station correctly with the buttons Tune+ 13 and Tune– 12.
	Reception is too weak.	Try to improve reception by moving the wire antenna 15.

NOTICE

► If you cannot solve the problem with the aforementioned methods, please contact Customer Service.

GB
CY

Storage/Disposal

Storage

If you do not intend to use the device for an extended period of time, disconnect it from the mains power supply, remove the battery and store it at a clean, dry location that is not subjected to direct sunlight.

Disposal of the device



Do not dispose of the device in your normal domestic waste. This product is subject to the European directive 2002/96/EC-WEEE (Waste Electrical and Electronic Equipment).

Dispose of the device through an approved disposal centre or at your community waste facility. Observe the currently applicable regulations. In case of doubt, please contact your waste disposal centre.

Disposing of the batteries

Batteries must not be disposed of in the household waste. Every consumer is legally obligated to hand in batteries at a collection centre in his/her community/district or a dealer. This obligation is intended to ensure that batteries are disposed of in an environmentally friendly manner. Hand batteries in only when they are fully discharged.

Appendix

Information regarding the EG conformity declaration

This device complies regarding conformance to the basic requirements and other relevant regulations of the European directive for electromagnetic compatibility 2004/108/EC, the low voltage directive 2006/95/EC as well as the Eco-design directive 2009/125/EC (Supplement 1275/2008 Appendix II, Nr.1)

The complete original declaration of conformity can be obtained from the importer.

Technical data

Operational voltage	220-240 V / 50 Hz	
Battery for data retention	1 x 3 V Type CR2032 (supplied)	
Power consumption		
Operation	approx. 5	W
Standby	approx. 1.8	W
Speaker power output:	approx. 1W (with 10 % harmonic distortion)	
Radio frequency range (VHF)	87.5 - 108 MHz	
Operating temperature	+5 - +40	°C
Humidity (no condensation)	5 - 90	%
Measurements (H x W x D): (without stand)	4.9 x 22 x 12	cm
Weight	approx. 600	g
Protection class	II ⧈	

GB
CY

Warranty

With this device you receive a 3 year warranty from the date of purchase. The device has been manufactured with care and meticulously examined before delivery.

Please retain your receipt as proof of purchase. In the case of a warranty claim, please get in touch, by telephone, with our service department. Only in this way can a post-free dispatch for your goods be assured.

NOTICE

- The warranty adjustment is valid only for material or manufacturing defects not, however, for transport damage, wear and tear or for damage to breakable parts, i.e. switches or rechargeable batteries.

The device is intended solely for private, non-commercial use. If this product has been subjected to improper or inappropriate handling, abuse, or modifications not carried out by one of our authorised sales and service outlets, the warranty becomes void.

Your statutory rights are not restricted in any way by this warranty. The warranty period will not be extended as a result of warranty adjustments. This applies also to replacement and repaired parts.

Possible damage and/or faults present at the time of purchase must be reported immediately after unpacking or, at the very latest, within two days after the purchase date.

After expiry of the warranty period incidental repairs are subject to payment.

Service

(GB) **DES UK LTD**
Tel.: 0871 5000 700 (£ 0.10 / minute)
E-Mail: support.uk@kompernass.com

(IE) **Kompernass Service Ireland**
Tel: 1850 930 412 (0,082 EUR/Min.)
Standard call rates apply. Mobile operators may vary.
E-Mail: support.ie@kompernass.com

(CY) **Kompernass Service Cyprus**
Tel: 800 9 44 01
E-Mail: support.cy@kompernass.com

Importer

KOMPERNASS GMBH

BURGSTRASSE 21

44867 BOCHUM, GERMANY

www.kompernass.com

HR

Sadržaj

Uvod. 28
Informacije u vezi sa ovim uputama za rukovanje 28
Autorsko pravo 28
Uporaba u skladu sa namjenom 28
Upozoravajuće napomene 29
Sigurnost 30
Opasnost uslijed električne struje. 30
Rukovanje sa baterijama 30
Opće sigurnosne napomene 31

Element za posluživanje. 32

Postavljanje i priključivanje. . . .33
Sigurnosne napomene. 33
Obim isporuke i transportna inspekcija . 33
Raspakiranje 33
Zbrinjavanje ambalaže 34
Zahtjevi u pogledu lokacije postavljanja. 34
Električni priključak 34
Umetanje baterije 35
Postavljanje pod visećim ormarom. . . .35
Demontaža 36
Postavljanje uređaja. 36
Snabdijevanje električnom energijom . 36
UKV - pokretna antena 36

Posluživanje i pogon 37
Uključivanje i isključivanje 37
Osnovna podešenja 37
Aktiviranje podesnog menija 37
Podešavanje točnog vremena 38
Podešavanje datuma 38
Podešavanje pozadinskog osvjetljenja na displayu 39
Podešavanje funkcije podsjećanja. . . .39
Podešavanje formata točnog vremena . 40
Kuhinjski timer 40
Podešavanje kuhinjskog timera 40
Pokretanje kuhinjskog timera 41
Prekidanje kuhinjskog timera 41
Programiranje kuhinjskog timera 42
Pozivanje kuhinjskog timera 42
Programiranje vremena buđenja 43
Buđenje sa zvukom alarma 43
Buđenje sa radio-programom 44
Isključivanje budilnika 44
Kada je došao trenutak za buđenje . . 44
Radio-pogon 45
Uključivanje/Isključivanje radio-prijemnika 45
Podešavanje glasnoće 45
Manualno podešavanje postaje 45
Traženje slijedećeg odašiljača. 45
Manualno pohranjivanje postaje. 46
Pozivanje pohranjene postaje 46
Automatsko traženje odašiljača (AMS-funkcija) 46
Daljnje funkcije 47
Automatsko isključivanje (funkcija drijemanja) 47
Blokada tipki 47
Pojačanje basova 47

Čišćenje 48
Sigurnosne napomene. 48
Čišćenje kućišta 48

Otklanjanje grešaka. 48
Sigurnosne napomene. 48
Uzroci i otklanjanje grešaka 49

Skladištenje/Zbrinjavanje 50
Skladištenje 50
Zbrinjavanje uređaja 50
Zbrinjavanje baterija 50

Prilog 51
Napomene u vezi sa EU-izjavom o konformitetu 51
Tehnički podaci 51
Jamstvo 52
Servis 52
Uvoznik 52

Uvod

HR

Informacije u vezi sa ovim uputama za rukovanje

Ove upute za rukovanje predstavljaju sastavni dio ugradbenog radio-prijemnika SKRD 30 A1 (u nastavku uređaj) i daju Vam važne napomene za namjensko korištenje, sigurnost, priključivanje i posluživanje uređaja.

Upute za rukovanje moraju stalno biti raspoložive u blizini uređaja. Ove upute mora čitati i primijeniti svaka osoba zadužena za posluživanje uređaja i otklanjanje smetnji.

Upute za rukovanje sačuvajte i predajte ih slijedećem vlasniku zajedno sa uređajem.

Autorsko pravo

Ova dokumentacija je zaštićena autorskim pravima.

Svako umnožavanje, odnosno svako naknadno tiskanje, čak i isječaka, kao i reprodukcija slika - i u promijenjenom obliku - dopušteno je isključivo uz pismeno odobrenje proizvođača.

Uporaba u skladu sa namjenom

Ovaj uređaj je namijenjen isključivo za prijem UKW-radio-programa, za funkciju kuhinjskog timera i za alarm pomoću alarmnog zvuka ili radio-programa u zatvorenim prostorijama. Uređaj je predviđen za slobodno postavljanje ili za montažu ispod ormara. U tu svrhu mora biti korišten isporučeni stalak, odnosno montažna ploča. Svaki drugi način uporabe i svaki način koji prelazi opisane okvire, smatra se nenamjenskim. Uređaj nije predviđen za uporabu u gospodarskim ili industrijskim područjima.

⚠ UPOZORENJE

Opasnost uslijed nenajmenske uporabe!

Od uređaja u slučaju nenamjenske uporabe i/ili drugih načina korištenja mogu polaziti razne opasnosti.

- ► Uređaj koristite isključivo na namjenski način.
- ► Pridržavajte se načina postupanja opisanih u ovim uputama za rukovanje.

Potraživanja svake vrste zbog oštećenja nastalih uslijed nenamjenske uporabe, nestručno izvedenih popravki, nedopuštenih preinaka uređaja ili korištenja nedopuštenih zamjenskih dijelova su isključena.

Rizik nosi isključivo korisnik uređaja.

Upozoravajuće napomene

U ovim uputama za rukovanje korištene su slijedeće upozoravajuće napomene:

⚠ OPASNOST

Upozoravajuća napomena ovog stupnja opasnosti označava prijeteću opasnu situaciju.

Ukoliko ne izbjegnete opasnu situaciju, to može dovesti do smrti ili do teških ozljeda.

- Pridržavajte se naputaka navedenih u ovoj upozoravajućoj napomeni, kako biste izbjegli opasnost nastupanja smrti ili teških ozljeda osoba.

⚠ UPOZORENJE

Upozoravajuća napomena ovog stupnja opasnosti označava moguću opasnu situaciju.

Ukoliko opasnu situaciju ne izbjegnete, to može dovesti do ozljeda.

- Pridržavajte se naputaka navedenih u ovoj upozoravajućoj napomeni, kako biste izbjegli opasnost ozljeda osoba.

PAŽNJA

Upozoravajuća napomena ovog stupnja opasnosti označava mogući nastanak predmetne štete.

Ukoliko ne izbjegnete ovu opasnu situaciju, to može dovesti do predmetne štete.

- Slijedite naputke navedene u ovoj upozoravajućoj napomeni, kako biste izbjegli nastanak predmetne štete.

NAPOMENA

- Napomena označava dodatne informacije, koje olakšavaju rukovanje s uređajem.

HR

Sigurnost

U ovom poglavlju možete pronaći važne sigurnosne napomene u vezi rukovanja uređajem.

Ovaj uređaj odgovara propisanim sigurnosnim odredbama. Nestručna uporaba može dovesti do ozljede osoba i do predmetne štete.

Opasnost uslijed električne struje

⚠ OPASNOST

Opasnost po život uslijed električne struje!

Prilikom kontakta sa vodovima ili gradbenim dijelovima pod naponom postoji opasnost po život!

Obratite pažnju na slijedeće sigurnosne napomene, kako biste izbjegli opasnost uslijed električne struje:

- Ne koristite uređaj, kada je mrežni utikač ili priključni kabel oštećen.
- Niukom slučaju ne otvarajte kućište uređaja. Ukoliko dodirnete priključke koji su pod naponom i pritom promijenite električni ili mehanički ustroj uređaja, postoji opasnost od strujnog udara.

Rukovanje sa baterijama

⚠ UPOZORENJE

Opasnost uslijed nestručnog rukovanja!

U cilju sigurnog rukovanja baterijama molimo da se pridržavate slijedećih sigurnosnih napomena:

- Baterije ne bacajte u vatru.
- Ne izazovite kratak spoj baterije.
- Ne pokušavajte baterije ponovo napuniti.
- U redovnim vremenskim razmacima kontrolirajte baterije. Iscurjela baterijska kiselina može izazvati trajna oštećenja uređaja. Posebno oprezni budite prilikom rukovanja sa oštećenim ili iscurjelim baterijama. Opasnost od nagrizanja! Nosite zaštitne rukavice.
- Baterije čuvajte na mjestu nedostupnom djeci. U slučaju gutanja neizostavno zatražite liječničku pomoć.
- Izvadite baterije, kada uređaj duže vrijeme ne koristite.

HR

Opće sigurnosne napomene

Za sigurno rukovanje uređajem uvažite slijedeće sigurnosne napomene:

- Uređaj prije uporabe kontrolirajte i pogledajte, da li postoje vidljiva vanjska oštećenja. Uređaj koji je oštećen ili koji je pao ne pustite u pogon.
- U slučaju oštećenja kablova ili priključaka iste dajte zamijeniti od autoriziranog stručnog personala ili servisa za kupce.
- Osobe, koje zbog svojih tjelesnih, duševnih ili motoričkih osobina nisu u stanju sigurno rukovati uređajem, isti smiju koristiti isključivo pod nadzorom ili po napucima odgovorne druge osobe.
- Djeci dopustite rukovanje uređajem isključivo pod nadzorom.
- Popravke uređaja smiju izvršiti isključivo autorizirane stručne radionice ili servis za kupce. Nestručno izvedene popravke mogu dovesti do opasnosti za korisnika. Osim toga jamstvo proizvođača prestaje važiti.
- Reparaturu uređaja za vrijeme jamstvenog roka smije izvršiti isključivo servis za kupce autoriziran od strane proizvođača, jer u protivnom ne postoji pravo na jamstvo u slučaju kasnijih oštećenja.
- Defektni gradbeni dijelovi smiju biti zamijenjeni isključivo originalnim zamjenskim dijelovima. Samo kod takvih zamjenskih dijelova je zajamčeno ispunjavanje sigurnosnih zahtjeva.
- Zaštitite uređaj od vlage i prodiranja tekućina. Uređaj nikada ne uronite u vodu, ne postavljajte ga u blizini vode i ne postavljajte na njega predmete napunjene tekućinom (na primjer vaze).
- Ne postavljajte nikakve predmete na uređaj.
- Uređaj ne koristite u blizini otvorenih plamena (npr. svijeća).
- Izbjegavajte neposredan utjecaj sunčeve svjetlosti.
- Dovod uvijek povlačite držanjem za priključni utikač, nikada ne povlačite za sam kabel.
- Ako dođe do smetnji ili u slučaju oluje izvucite mrežni utikač iz utičnice.

Element za posluživanje

HR

(Slike pronađite na isklopnoj stranici, slika A)

1. Montažna ploča/Stalak
2. Komandno polje
3. Display
4. On/Off: Uključivanje/Isključivanje (radio)
5. AOT: Timer isključivanja
6. Lock/Mem.: Blokada za tipke/odabir memorijskog mjesta
7. Bass/AMS/Mode: Podizanje basova/automatsko traženje postaje/pozivanje podesnog menija
8. Alarm 1: Alarm 1 programiranje
9. Alarm 2: Alarm 2 programiranje
10. Preset–: pozivanje prethodnog memorijskog mjesta
11. Preset+: pozivanje slijedećeg memorijskog mjesta
12. Tune–: smanjenje prijemne frekvencije
13. Tune+: povećanje prijemne frekvencije
14. VOLUME/Snooze/Timer: Reguliranje glasnoće/isključivanje alarma/podešavanje timera
15. Pokretna antena za UKW-prijem
16. Mrežni priključni kabel
17. Utori za stalak
18. Zvučnik
19. Pretinac za baterije
20. Tipke za deblokadu montažne ploče

Postavljanje i priključivanje

Sigurnosne napomene

⚠ UPOZORENJE

Prilikom puštanja uređaja u rad može doći do predmetne štete i do ozljeda osoba!

Obratite pažnju na slijedeće sigurnosne napomene, kako biste izbjegli opasnosti:

- ► Materijali pakiranja ne smiju biti korišteni za igru. Postoji opasnost od gušenja.
- ► Obratite pažnju na napomene u vezi sa zahtjevima u pogledu mjesta postavljanja i u pogledu električnog priključka uređaja, kako biste izbjegli ozljede i nastanak predmetne štete.

Obim isporuke i transportna inspekcija

Uređaj se standardno isporučuje sa slijedećim komponentama:

- Ugradbeni radio SKRD 30 A1
- Montažna ploča/stalak
- 4 vijka za učvršćavanje
- 1 x baterija 3 V tipa CR2032
- Upute za uporabu

NAPOMENA

- ► Ispitajte cjelovitost obima isporuke i provjerite, postoje li vidljiva oštećenja.
- ► U slučaju nepotpune isporuke ili oštećenja uslijed oskudnog pakiranja ili transportnih oštećenja molimo da se obratite dežurnoj servisnoj telefonskoj liniji (vidi poglavlje ***Servis***).

Raspakiranje

- ♦ Izvadite sve dijelove uređaja i upute za rukovanje iz kartona.
- ♦ Odstranite cjelokupni materijal pakiranja.

HR

Zbrinjavanje ambalaže

Pakiranje (ambalaža) uređaj štiti od transportnih oštećenja. Materijali ambalaže su izabrani u skladu sa načelima za očuvanje okoliša i načelima tehnologije zbrinjavanja otpada, te su zbog toga prikladni za recikliranje.



Povrat pakiranja u kružni tok materijala štedi sirovine i smanjuje količinu nastalog otpada. Materijale pakiranja, koji Vam više nisu potrebni, zbrinite u skladu sa važećim mjesnim propisima.

NAPOMENA

► Ako je moguće, sačuvajte originalno pakiranje za vrijeme važenja jamstvenog roka uređaja, kako biste uređaj u slučaju korištenja prava na jamstvo mogli uredno zapakirati.

Zahtjevi u pogledu lokacije postavljanja

Za siguran i pouzdan rad uređaja bez grešaka mjesto postavljanja mora zadovoljiti slijedeće uvjete:

- Prilikom postavljanja uređaj postavite na čvrstu, ravnu i vodoravnu podlogu. Koristite priloženi stalak.
- Uređaj tako postavite ili montirajte, da postojeći ventilacijski otvori i zvučnik ne budu prekriveni.
- Uređaj ne pogonite u vrućem, mokrom ili vrlo vlažnom okruženju, niti u blizini zapaljivih materijala.
- Površine elemenata namještaja mogu sadržavati tvari agresivne za gumene nogice uređaja, koje iste mogu razmekšati. Po potrebi podmetnite podlogu pod gumene nogice uređaja.
- Utičnica mora biti lako dostupna, tako da mrežni utikač u slučaju opasnosti brzo može biti izvučen.

Električni priključak

- Prije priključivanja uređaja usporedite podatke za priključak (napon i frekvenciju) na tipskoj ploči sa vrijednostima Vaše strujne mreže. Ovi podaci moraju biti podudarni, kako ne bi došlo do oštećenja uređaja.
- Provjerite, da li je priključni kabel uređaja neoštećen i osigurajte, da ne bude postavljen tako da prelazi preko vrućih površina i/ili oštrih ivica.
- Obratite pažnju na to, da priključni kabel ne bude zategnut ili savijen.
- Ne pustite priključni kabel da visi preko kutova (opasnost od protepanja).

Umetanje baterije

Umetanjem baterije izbjeći ćete, da u slučaju nestanka struje dođe do gubljenja programiranog točnog vremena i podešenog vremena alarma. Baterija omogućava nastavak rada internog sata i za vrijeme nestanka struje. Kada se struja ponovo pojavi, na displayu 3 će automatski biti prikazano ispravno točno vrijeme.

NAPOMENA

► Uređaj može raditi i bez baterija.

- Otvorite poklopac pretinca za baterije 19 na donjoj strani uređaja tako, što ćete pokrov pomoću kovanice do kraja okrenuti u lijevu stranu i istu odići.
- Umetnite bateriju tipa CR2032 (sadržana u obimu isporuke) u pretinac za baterije. Strana sa oznakom + okrenuta je prema gore.
- Zatvorite pretinac za baterije tako, što ćete postaviti pokrov i pomoću kovanice ga okrenuti u desnu stranu.

Postavljanje pod visećim ormarom

(Sliku možete pronaći na isklopnoj stranici, slika B)

Uređaj možete sa priloženom montažnom pločom 1 na primjer montirati pod visećim ormarom. Montažu uređaja izvedite na slijedeći način:

- Pritisnite dvije tipke za deblokadu 20 smještene na stražnjoj strani uređaja prema dolje, pritom istovremeno gurnite montažnu ploču 1 prema natrag i skinite montažnu ploču 1.
- Potražite prikladno mjesto za uređaj (vidi i poglavlje ***Zahtjevi za mjesto postavljanja***).
- Držite montažnu ploču 1 pod mjesto postavljanja. Pritom se treba prednja ivica montažne ploće 1 ca. 4 cm nalaziti iza čeone strane visećeg ormara, tako da uređaj nakon montaže bude u jednoj ravni sa visećim ormarom.
- Označite 4 točke za učvršćenje pomoću klina.
- Sa klinom ili čavlom napravite malu udubinu na mjestima označavanja. Pričvrstite montažnu ploču 1 uz pomoć priloženih vijaka, na način prikazan na slici B.
- Umetnite uređaj koso, sa prednjim utorima u gornjoj strani uređaja u montažnu ploču 1. Pritisnite stražnji dio uređaja prema gore u montažnu ploču 1, sve dok uređaj čujno ne ulegne.
- Provjerite siguran položaj uređaja.

HR

Demontaža

- Pritisnite dvije tipke za deblokadu 20 na stražnjoj strani uređaja prema dolje, pritom istovremeno uređaj gurnite prema naprijed i izvadite uređaj prema donjoj strani.
- Okrenite vijke na montažnoj ploči 1 prema van i montažnu ploču 1 skinite.

Postavljanje uređaja

Alternativno možete i postaviti uređaj. Da prilikom postavljanja ventilacijske otvore i zvučnik 18 na donjoj strani uređaja ne biste prekrili, uređaj mora na stalku 1 biti montira. Montažu stalka izvedite na slijedeći način:

- Pritisnite dvije tipke za deblokadu 20 smještene na stražnjoj strani uređaja prema dolje, pritom istovremeno gurnite montažnu ploču 1 prema natrag i skinite montažnu ploču 1. Montažna ploča sada funkcionira kao stalak.
- Gurnite dva prednja držača stalka 1 u stražnje utore 17 na donjoj strani uređaja.
- Gurnite dva stražnja držača stalka 1 u prednje utore 17 na donjoj strani uređaja, sve dok stalak čujno ne ulegne u svoje ležište.
- Potražite prikladno mjesto za postavljanje uređaja (vidi i poglavlje ***Zahtjevi za mjesto postavljanja***).

Snabdijevanje električnom energijom

- Utaknite mrežni utikač priključnog mrežnog kabela 16 u utičnicu. Na displayu 3 će točno vrijeme (0:00 Uhr) biti prikazano.

UKV - pokretna antena

- Odmotajte pokretnu antenu 15 za UKV-prijem potpuno.

Posluživanje i pogon

U ovom poglavlju možete pronaći važne napomene u vezi sa posluživanjem i radom uređaja.

Uključivanje i isključivanje

Nakon priključivanja na struju uređaj će već biti uključen. Preko tipke On/Off ❹ možete vršiti prebacivanje između pogonskih modusa Sat/standby i radio.

NAPOMENA

► Prekidač On/Off ❹ uređaj ne odvaja potpuno od strujne mreže. Da biste uređaj potpuno odvojili od strujne mreže, morate mrežni utikač priključnog mrežnog kabela ⓰ izvaditi iz utičnice.

Osnovna podešenja

Nakon priključivanja uređaja na izvor struje uređaj na displayu ❸ prikazuje točno vrijeme i dan u tjednu. Uređaj se nalazi u pogonskom modusu Sat/standby.

Aktiviranje podesnog menija

Za aktiviranje podesnog menija pritisnite u pogonskom modusu Sat/standby tipku Bass/AMS/Mode ❼. U displayu ❸ prikazani sat počinje treptati. Svako dodatno aktiviranje tipke Bass/AMS/Mode ❼ prebacuje na slijedeću opciju podešavanja. Redosljed točaka menija je slijedeći:

- Podešavanje točnog vremena
- Podešavanje datuma
- Podešavanje svijetlosti prikaza na displayu
- Podešavanje funkcije podsjećanja
- Podešavanje formata točnog vremena

NAPOMENA

► Podesni meni će se automatski završiti, ako ca. 15 sekundi ne pritisnete niti jednu tipku. Izvršena podešenja se memoriraju.

HR

Podešavanje točnog vremena

Pretpostavka: Uređaj se nalazi u pogonskom modusu Sat/standby.

- Pritisnite tipku Bass/AMS/Mode ❼ jedanput. Prikaz točnog vremena počinje treptati.
- Podesite pomoću tipke Tune+ ⓭ i Tune– ⓬ aktualno točno vrijeme. Jednim aktiviranjem tipke vrijeme će se promijeniti za po jednu minutu. Držanje dotične tipke duže od 2 sekunde pokreće brzo podešavanje.
- Pritisnite tipku Bass/AMS/Mode ❼ ponovo, da biste pohranili aktualne postavke i prešli na slijedeću točku menija.

NAPOMENA

► Točno vrijeme će biti vraćeno na 00:00 sati, ako uređaj odvojite od strujne mreže, ukoliko nije umetnuta baterija ili je baterija preslaba.

Podešavanje datuma

Pretpostavka: Uređaj se nalazi u pogonskom modusu Sat/standby.

- Pritisnite tipku Bass/AMS/Mode ❼ dvaput. Prikaz datuma počinje treptati.
- Podesite pomoću tipke Tune+ ⓭ i Tune– ⓬ aktualni datum. Svakim pritiskanjem tipke datum će biti promijenjen za po jedan dan. Prikaz dana u tjednu automatski se mijenja. Držanje dotične tipke duže od 2 sekunde pokreće brzo podešavanje.
- Pritisnite tipku Bass/AMS/Mode ❼ ponovo, da biste pohranili aktualnu postavku i prešli na slijedeću točku menija.

NAPOMENA

► Datum će biti vraćen na 01.01.2010, ako uređaj odvojite od strujne mreže, ukoliko nije umetnuta baterija ili je baterija preslaba.

Podešavanje pozadinskog osvjetljenja na displayu

Pretpostavka: Uređaj se nalazi u pogonskom modusu Sat/standby.

- Pritisnite tipku Bass/AMS/Mode 7 triput. Aktualno podešenje pozadinskog osvjetljenja displaya je prikazano (H=svijetlo ili L=tamno).
- Podesite pomoću tipke Tune+ 13 osvjetljenje displaya na H, ako želite snažnije osvjetljenje displaya.
- Podesite pomoću tipke Tune– 12 osvjetljenje displaya na L, ako želite slabije osvjetljenje displaya.
- Pritisnite tipku Bass/AMS/Mode 7 ponovo, da biste aktualnu postavku pohranili i prešli na slijedeću točku menija.

Podešavanje funkcije podsjećanja

Možete podesiti do 10 vrijednosti datuma, na kojima će biti aktivirano automatsko podsjećanje. Funkcija SdA (SdA=Special Day Alert) je korisna, da bi Vas na primjer podsjetila na rođendane ili na druge događaje, koji se periodično ponavljaju. Podsjećanje će biti izvršeno svake godine na isti dan.

Pretpostavka: Uređaj se nalazi u pogonskom modusu Sat/standby.

- Pritisnite tipku Bass/AMS/Mode 7 četiri puta. Aktualna postavka odabranog datuma za podsjećivanje biti će naizmjenično sa dojavom SdA prikazana. Osim prikaza dojave SdA broj memorijskog mjesta označava datum. Moguće vrijednosti su SdA 01 do SdA 10.
- Izaberite sa tipkama Preset+ 11 i Preset– 10 memorijsko mjesto datuma, koji želite podesiti.
- Podesite pomoću tipke Tune+ 13 i Tune– 12 datum za to memorijsko mjesto. Svakim pritiskanjem tipke datum će biti promijenjen za po jedan dan. Držanje dotične tipke duže od 2 sekunde pokreće brzo podešavanje.

NAPOMENA

► Pritisnite tipku AOT 5 ,ako funkciju podsjećanja za aktualno odabrano memorijsko mjesto želite isključiti. Na displayu se -- -- pojavljuje.

- Pritisnite tipku Lock/Mem. 6, da biste točno vrijeme, u koje dolazi do aktiviranje funkcije podsjećanja, podesili. Podešenje vršite sa tipkama Tune+ 13 i Tune– 12 na svaki puni sat između 00 i 23. Ova postavka vrijedi za sve programirane termine za podsjećivanje
- Pritisnite tipku Bass/AMS/Mode 7 ponovo, da biste aktualno podešenje pohranili i prešli na slijedeću točku menija.

HR

Podešavanje formata točnog vremena

Pretpostavka: Uređaj se nalazi u pogonskom modusu Sat/standby.

- Pritisnite tipku Bass/AMS/Mode ❼ pet puta. Aktualno podešenje formata točnog vremena biti će prikazano (24=24-satni format ili 12=12-satni format).
- Postavite s tipkom Tune+ ⓭ format točnog vremena na 24, ako želite prikaz točnog vremena u 24-satnom formatu .
- Postavite s tipkom Tune– ⓬ format točnog vremena na 12, ako želite prikaz točnog vremena u 12-satnom formatu .
- Pritisnite tipku Bass/AMS/Mode ❼ ponovo, da biste pohranili aktualnu postavku i prešli na slijedeću točku menija.

Kuhinjski timer

Uređaj raspolaže praktičnim kuhinjskim timerom, sa kojim na primjer mogu biti nadzirana vremena kuhanja i pečenja. Podesivo vremensko područje kuhinjskog timera je između 1 minute i 23 sata i 59 minuta.

Podešavanje kuhinjskog timera

- Pritisnite tipku Snooze/Timer ⓮. Pojavljuje se prikaz 00:00. U desnom gornjem kutu displaya pojavljuje se simbol lonca za kuhinjski timer.
- Okrenite gumb VOLUME ⓮, da biste podesili vremensko područje za kuhinjski timer. Okretanje u smjeru kazaljke sata povećava vrijeme; Okretanje u smjeru protivnom kazaljci sata umanjuje vrijeme.

NAPOMENA

► Ako za vrijeme podešavanja u trajanju od ca. 15 sekundi ne izvršite niti jednu promjenu, uređaj automatski prelazi u prethodni pogonski modus.

Pokretanje kuhinjskog timera

♦ Nakon podešavanja vremena pritisnite tipku Snooze/Timer 14 ponovo. Prikazano vrijeme počinje teći unatraške. U desnom gornjem kutu displaya pojavljuje se simbol sata, koji teče unatraške.

NAPOMENA

► Ukoliko za vrijeme odbrojavanja kuhinjskog timera odaberete drugu funkciju, nestati će prikaz preostalog vremena. Simbol lonca i simbol sata koji teče unatraške će međutim i dalje biti prikazani u desnom gornjem kutu displaya. Pritisnite tipku Snooze/Timer 14 ponovo, da biste ponovo pozvali prikaz preostalog vremena kuhinjskog timera.

30 sekundi prije isteka kuhinjskog timera uređaj započinje sa pojedinačnim signalnim zvukovima upozoravati na dostizanje podešenog vremena. Razmaci pojedinačnih zvukova su pritom sve kraći. Nakon dostizanja podešenog vremena oglašava se alarmni signal kuhinjskog timera kao trajni interval.

♦ Pritisnite tipku Snooze/Timer 14, da biste alarmni signal kuhinjskog timera isključili.

Prekidanje kuhinjskog timera

♦ Pritisnite na aktiviranom kuhinjskom timeru tipku Snooze/Timer 14. Kuhinjski timer se zaustavlja. Prikazano preostalo vrijeme trepti.

NAPOMENA

► Uređaj se nakon ca. 15 sekundi ponovo vraća na prethodni pogonski modus. Pritisnite tipku Snooze/Timer 14 ponovo, da biste prikaz preostalog vremena kuhinjskog timera ponovo pozvali.

♦ Da biste ponovo pokrenuli kuhinjski timer, pritisnite tipku Snooze/Timer 14 ponovo. Kuhinjski timer se ponovo pokreće.

♦ Da biste kuhinjski timer isključili prije isteka vremena, pritisnite i držite tipku Snooze/Timer 14 najmanje 2 sekunde.

HR

Programiranje kuhinjskog timera

Često korištena vremena za kuhinjski timer možete programirati unaprijed, kako ih ne biste svaki puta ponovo morali unositi. Mogu biti unaprijed programirana najviše 10 vremena. Svih 10 programskih mjesta su standardno unaprijed programirana na vrijednost od 10 minuta.

Za programiranje kuhinjskog timera postupite na slijedeći način:

- Pritisnite tipku Snooze/Timer 14, da biste aktivirali kuhinjski timer.
- Okrenite gumb VOLUME 14, da biste podesili vrijeme, koje treba biti programirano. Okretanje u smjeru kazaljke sata povećava vrijeme; Okretanje u smjeru protivnom kazaljci sata umanjuje vrijeme.
- Pritisnite tipku Lock/Mem. 6, da biste aktivirali izbor timera. Ispod simbola lonca za označavanje kuhinjskog timera pojavljuje se treptući T.
- Birajte sa tipkama Preset+ 11 i Preset– 10 memorijsko mjesto za timer, koji treba biti podešen, u rasponu između T0 i T9.
- Pritisnite tipku Lock/Mem. 6 ponovo, da biste programirali podešeno vrijeme na izabranom memorijskom mjestu. Treptući T ispod simbola lonca sada će biti konstantno prikazano.
- Ponovite ovaj postupak za ostala memorijska mjesta.

Pozivanje kuhinjskog timera

Da biste pozvali programirano vrijeme za kuhinjski timer, postupite na slijedeći način:

- Pritisnite tipku Snooze/Timer 14, da biste aktivirali kuhinjski timer.
- Birajte sa tipkama Preset+ 11 i Preset– 10 željeni timer u rasponu između T0 i T9.
- Pritisnite tipku Snooze/Timer 14 ponovo, da biste pokrenuli kuhinjski timer.

Programiranje vremena buđenja

Uređaj raspolaže sa dva budilnika. Sva podešenja mogu biti vršena za oba budilnika neovisno. Možete birati, da li se u programiranom vremenu treba oglasiti alarmni ton ili uključiti radio.

NAPOMENA

► Ako za vrijeme programiranja vremena buđenja ca. 15 sekundi ne pritisnete niti jednu tipku, vrijeme buđenja će biti aktivirano sa aktualnim postavkama.

Pretpostavka: Uređaj se nalazi u pogonskom modusu Sat/standby.

Za podešavanje vremena buđenja postupite na slijedeći način:

- Pritisnite Alarm1-tipku 8 ili Alarm2-tipku 9. Podešeno vrijeme buđenja za određeni alarm treptati će na displayu 3 i prikaz A1 odnosno A2 se pojavljuje. Iznad prikaza vremena biti će prikazani dani u tjednu, na kojima je ovaj alarm aktivan.
- Sa tipkama Tune+ 13 i Tune– 12 podesite željeno vrijeme za buđenje. Jednim aktiviranjem tipke vrijeme za buđenje biti će promijenjeno za po jednu minutu. Držanje dotične tipke duže od 2 sekunde pokreće brzo podešavanje.
- Pritisnite tipku AOT 5, da biste između kombinacija dana u tjednu pon-pet, sub-ned ili pon-ned prebacivali. Odabrana kombinacija biti će prikazana iznad vremena za buđenje.
- Pritisnite i držite tipku AOT 5 najmanje 2 sekunde, da biste prebacivali između kombinacija dana u tjednu i mogućnosti podešavanja pojedinačnog dana u tjednu.

NAPOMENA

► Kod podešavanja pojedinačnog dana u tjednu prebacujete pomoću tipke AOT 5 sa jednog na drugi dan u tjednu.

Buđenje sa zvukom alarma

Pretpostavka: Uređaj se nalazi u pogonskom modusu Sat/standby.

- Da biste za određeni budilnik izabrali "Zvuk alarma", pritisnite Alarm1-tipku 8 ili Alarm2-tipku 9 više puta uzastopno, dok se na displayu 3 simbol ne pojavi.

HR

Buđenje sa radio-programom

Ako želite biti probuđeni sa radio-programom, prije aktiviranja vremena buđenja izvršite slijedeća podešenja:

- Uključite radio tako, što ćete tipku On/Off ❹ pritisnuti.
- Izaberite postaju, koja Vas treba probuditi (vidi poglavlje ***Podešavanje postaje***).
- Podesite pomoću dugmeta VOLUME ⓮ željenu glasnoću (vidi poglavlje ***Podešavanje glasnoće***).
- Isključite radio tako, što ćete tipku On/Off ❹ pritisnuti.
- Da biste za odgovarajući budilnik izabrali „radio“, pritisnite Alarm1-tipku ❽ ili Alarm2-tipku ❾ više puta uzastopno, sve dok se na displayu ❸ simbol ⏲ ne pojavi.

Isključivanje budilnika

Pretpostavka: Uređaj se nalazi u pogonskom modusu Sat/standby.

- Da biste budilnik isključili, pritisnite Alarm1-tipku ❽ ili Alarm2-tipku ❾ više puta uzastopno, sve dok na displayu ❸ više ne bude prikazan niti jedan simbol.

Kada je došao trenutak za buđenje

Kod postavke **„Buđenje sa zvukom alarma“** se u razmacima od po 2 sekunde oglašava četverostruki signalni zvuk. Glasnoća signalnog zvuka se kontinuirano povećava sve do postizanja maksimalne glasnoće. Trajanje signala za buđenje ograničeno je na 10 minuta.

Kod postavke **„Buđenje radio-programom“** uključuje se radio-prijemnik. Prethodno izabrana postaja biti će aktivirana podešenom glasnoćom u trajanju od maksimalno 60 minuta.

- Pritisnite tipku Snooze/Timer ⓮, da biste aktivirali ponavljanje buđenja nakon 9 minuta.

NAPOMENA

► Ponavljanje buđenja moguće je najkasnije 60 minuta nakon dostizanja podešenog vremena buđenja.

- Pritisnite Alarm1-tipku ❽ ili Alarm2-tipku ❾, da biste okončali aktualni alarm.

NAPOMENA

► Alarm će u trenutku dostizanja slijedećeg vremena za buđenje (na primjer slijedećeg dana) ponovo biti aktivan.

Radio-pogon

NAPOMENA

- ► Za dobar radio-prijem morate pokretnu antenu ⑮ potpuno odmotati. Antenu u radio-pogonu usmjerite tako, da bude postignut najbolji mogući prijem.
- ► Tehničke osobine uređaja omogućuju podesivu frekvenciju prijema izvan dopuštenog područja UKW (FM)-pojasa od 87,5–108 MHz. U raznim zemljama mogu postojati različite nacionalne odredbe u vezi sa dodijeljenim krugovalnim frekvencijskim područjima. Obratite pažnju na to, da informacije primljene izvan dodijeljenog frekvencijskog krugovalnog područja ne smijete koristiti, proslijediti trećim osobama ili zloupotrebljavati suprotno njihovoj namjeni.

Uključivanje/Isključivanje radio-prijemnika

- ♦ Uključite radio tako, što ćete tipku On/Off ④ pritisnuti. Display ③ prikazuje aktualnu frekvenciju prijema podešene postaje.
- ♦ Isključite radio tako, što ćete tipku On/Off ④ ponovo pritisnuti. Uređaj se vraća u pogonski modus Sat/standby. Pojavljuje se aktualno točno vrijeme.

Podešavanje glasnoće

- ♦ Pomoću VOLUME-regulatora ⑭ podesite željenu glasnoću. Okretanje u smjeru kazaljke sata povećava glasnoću; Okretanje u smjeru protivnom kazaljci sata umanjuje vrijeme. Razina glasnoće biti će na lijevom rubu displaya ③ prikazana.

Manualno podešavanje postaje

- ♦ Pojedinačnim pritiskanjem tipke Tune+ ⑬ i Tune– ⑫ možete podesiti željenu postaju. Frekvencija odašiljača biti će na displayu ③ prikazana. Zvučnik je za vrijeme podešavanja isključen.

Traženje slijedećeg odašiljača

Uređaju možete naložiti da automatski traži slijedeći odašiljač.

- ♦ Pritisnite i držite tipku Tune+ ⑬ ili Tune- ⑫ najmanje dvije sekunde. Uređaj traži najbližu slijedeću postaju sa dostatnom kvalitetom prijema.
- ♦ Ponovite ovaj postupak, sve dok ne pronađete traženu postaju.

HR

Manualno pohranjivanje postaje

Pretpostavka: Uređaj se nalazi u pogonskom modusu Radio.

Uređaj na raspolaganje stavlja 30 memorijskih mjesta za emisione frekvencije. Za pohranjivanje odašiljačke frekvencije postupite na slijedeći način:

- Željenu postaju podesite na prethodno opisani način.
- Pritisnite tipku Lock/Mem. ❻ jedanput. Simbol MEM u donjem desnom kutu displaya počinje treptati.
- Izaberite sa tipkama Preset+ ⓫ i Preset– ⓾ željeno memorijsko mjesto za podešenu postaju u rasponu između *1* i *30*.
- Pritisnite tipku Lock/Mem. ❻ ponovo. Frekvencija prijema podešenog odašiljača biti će pohranjena na izabranom memorijskom mjestu. Simbol MEM svijetli konstantno.

Pozivanje pohranjene postaje

Pretpostavka: Uređaj se nalazi u pogonskom modusu Radio.

- Izaberite sa tipkama Preset+ ⓫ ili Preset– ⓾ željeno memorijsko mjesto za pohranjenu postaju u rasponu između *1* i *30*.

Automatsko traženje odašiljača (AMS-funkcija)

Pretpostavka: Uređaj se nalazi u pogonskom modusu Radio.

Da biste memorijska mjesta za odašiljačke frekvencije dodijelili najjačim postajama, možete provesti automatsko traženje odašiljača.

NAPOMENA

► Prilikom izvođenja u nastavku opisane funkcije doći će do gubljenja svih prethodno pohranjenih postaja.

- Pritisnite i držite tipku Bass/AMS/Mode ❼ najmanje dvije sekunde. Uređaj započinje sa traženjem odašiljača i dodjeljuje memorijskim mjestima 1-30 pronađene postaje.

NAPOMENA

► Ako uređaj pronađe više od 30 postaja, biti će pohranjene samo 30 prve odašiljačke frekvencije.

► Ako uređaj pronađe manje od 30 postaja, zadnja memorijska mjesta ostaju nepromijenjena.

Daljnje funkcije

Automatsko isključivanje (funkcija drijemanja)

Sa funkcijom drijemanja radio se nakon vremenskog razdoblja u trajanju od 5 do 120 minuta samostalno isključuje.

- Pritisnite tipku AOT (5), da biste funkciju pozvali. Aktualno preostalo vrijeme do isključivanja radio-prijemnika biti će prikazano.
- Pritisnite tipku AOT (5) ponovo, da biste podesili željeno vrijeme. Držanje dotične tipke duže od 2 sekunde pokreće brzo podešavanje.

NAPOMENA

► Podesivi vremenski raspon iznosi između 5 i 120 minuta. Podešavanje se vrši u koracima od po 5 minuta. Nakon toga se pojavljuje prikaz OFF. Kod prikaza OFF funkcija drijemanja je isključena.

Blokada tipki

Tipke uređaja možete blokirati, tako da neovlaštene osobe ili djeca ne mogu vršiti promjenu postavki.

- Pritisnite i držite tipku Lock/Mem. (6) najmanje dvije sekunde, da biste uključili ili isključili blokadu tipki. Kod uključene blokade tipki na displayu će se pojaviti simbol .

Pojačanje basova

S pojačanjem basova možete uključiti pojačanu reprodukciju dubokih frekvencija.

Pretpostavka: Uređaj se nalazi u pogonskom modusu Radio.

- Nakratko pritisnite tipku Bass/AMS/Mode (7), da biste uključili ili isključili pojačanje basova. Kod uključenog pojačanja basova će se na displayu pojaviti simbol BASS.

Čišćenje

HR

Sigurnosne napomene

⚠ OPASNOST

Opasnost po život uslijed električne struje

► Izvucite mrežni utikač iz utičnice, prije nego što započnete sa čišćenjem uređaja.

PAŽNJA

Oštećenje uređaja!

► Osigurajte, da prilikom čišćenja ne dođe do prodiranja tekućine u uređaj, kako biste izbjegli nepopravljivo oštećenje uređaja.

Čišćenje kućišta

■ Površine uređaja očistite sa mekom i suhom krpom.

Otklanjanje grešaka

U ovom poglavlju možete pronaći važne napomene za lokaliziranje smetnji i njihovo otklanjanje. Uvažite ove napomene, kako biste opasnosti i oštećenja izbjegli.

Sigurnosne napomene

⚠ UPOZORENJE

Obratite pažnju na slijedeće sigurnosne napomene, kako biste izbjegli opasnosti i predmetne štete:

► Popravke električnih uređaja smiju vršiti isključivo stručnjaci podučeni od proizvođača. Nestručno izvedene popravke mogu izazvati znatne opasnosti za korisnika i dovesti do oštećenja uređaja.

Uzroci i otklanjanje grešaka

Slijedeća tablica će Vam pomoći u lokaliziranju i otklanjanju manjih smetnji:

Pogreška	Mogući uzrok	Otklanjanje
Display ništa ne prikazuje.	Mrežni utikač nije utaknut.	Utaknite mrežni utikač u utičnicu.
	Utičnica ne isporučuje napon.	Provjerite osigurače u domaćinstvu.
Nema tona	Glasnoća je postavljena na minimalnu vrijednost.	Povećajte glasnoću pomoću VOLUME-regulatora 14.
	Radio je isključen.	Radio pomoću tipke On/Off 4 uključite.
Ometajući šumovi prilikom prijema radio-programa	Postaja nije ispravno podešena.	Odašiljač sa tipkom Tune+ 13 i Tune– 12 ispravno podesite.
	Prijem je preslab.	Pokušajte pokretanjem antene 15 poboljšati prijem.

NAPOMENA

► Ako sa naprijed navedenim koracima niste uspjeli riješiti problem, molimo da se obratite servisu za kupce.

Skladištenje/Zbrinjavanje

HR

Skladištenje

Ukoliko uređaj ne koristite duže vrijeme, odvojite ga od napajanja strujom, izvadite bateriju i uređaj skladištite na čistom i suhom mjestu bez neposrednog utjecaja sunčeve svjetlosti.

Zbrinjavanje uređaja



Uređaj niukom slučaju ne bacajte u obično kućno smeće. Ovaj proizvod podliježe europskoj smjernici 2002/96/EC-WEEE (Waste Electrical and Electronic Equipment).

Uređaj otklonite preko ovlaštenog poduzeća za otklanjanje otpada ili preko vašeg komunalnog poduzeća za otklanjanje otpada. Obratite pažnju na aktualne važeće propise. U slučaju dvojbe se povežite sa Vašom ustanovom za zbrinjavanje.

Zbrinjavanje baterija

Baterije ne smiju biti zbrinute sa kućnim smećem. Svaki potrošač je zakonski obavezan baterije predavati na sabirnom mjestu njegove općine/njegovog kvarta ili u trgovini. Ova obaveza služi za to, da baterije mogu biti zbrinute na ekološki ispravan način. Baterije vratite isključivo u ispražnjenom stanju.

Prilog

Napomene u vezi sa EU-izjavom o konformitetu

Ovaj uređaj odgovara osnovnim zahtjevima i drugim relevantnim propisima europske smjernice za elektromagnetnu podnošljivost 2004/108/EC, niskonaponske smjernice 2006/95/EC i smjernice za ekološki dizajn 2009/125/EC (naputak 1275/2008 prilog II, br.1).

Cjelokupnu originalnu izjavu o konformitetu možete nabaviti kod uvoznika.

Izjava o sukladnosti za ovaj proizvod dostupna je na internet stranici www.lidl.hr.

Tehnički podaci

Pogonski napon	220-240 V / 50 Hz	
Baterija za osiguranje podataka	1 x 3 V tip CR2032 (sadržane u obimu isporuke)	
Snaga uređaja		
Pogon	ca. 5	W
Standby	ca. 1,8	W
Izlazna snaga zvučnika:	ca. 1 W (sa 10 % šumova)	
Frekvencijsko područje radio (UKW)	87,5 - 108 MHz	
Pogonska temperatura	+5 - +40	°C
Vlaga (bez kondenzacije)	5 - 90	%
Dimenzije (V x Š x D) (bez stalka)	4,9 x 22 x 12	cm
Težina	ca. 600	g
Zaštitna klasa	II ⧈	

HR

Jamstvo

Na ovaj uređaj dobivate jamstvo u trajanju od 3 godine od datuma kupnje. Uređaj je pažljivo proizveden i prije isporuke brižljivo kontroliran.

Molimo sačuvajte blagajnički račun kao dokaz o kupnji. Molimo vas, da se u slučaju garancije telefonski povežete sa svojom servisnom ispostavom. Samo na taj način vaša roba može biti besplatno uručena.

NAPOMENA

► Jamstvo vrijedi isključivo za greške materijala ili greške u izradi, a ne za transportne štete, potrošne dijelove ili za oštećenja lomljivih dijelova, na primjer prekidača ili baterija.

Proizvod je namijenjen isključivo za privatnu, a ne za gospodarsku uporabu. U slučaju zlouporabe i nestručnog rukovanja, primjene sile i zahvata, koje nije izvršila naša autorizirana servisna ispostava, jamsto prestaje važiti.

Vaša zakonska prava ovim jamstvom ostaju netaknuta. Jamstveni rok se ne produžava korištenjem prava na jamstvo. To vrijedi i za zamijenjene i popravljene dijelove.

Eventualno već prilikom kupnje postojeće štete i nedostaci moraju biti javljeni odmah nakon raspakiranja, najkasnije međutim dva dana nakon datuma kupnje.

Popravke vršene nakon isteka jamstvenog roka podliježu obavezi plaćanja.

Servis

HR **Ovlašteni servis: Microtec sistemi d.o.o.**
Tel.: 01/3692-008
E-Mail: support.hr@kompernass.com

Uvoznik

Lidl Hrvatska d.o.o. k.d.,
p.p. 61
10020 Novi Zagreb

Proizvođač:

KOMPERNASS GMBH

BURGSTRASSE 21

D-44867 BOCHUM, Njemačka